


PORTER-CABLE CORDLESS DRIVER/DRILL

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.



Parts List for 9830 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
1	000000-00	No Longer Available	1
4	887031	SWITCH	1
4	000000-00	No Longer Available	1
53	886338	GEAR BOX/CLUTCH ASSY	1
54	884408	GRADUATED RING	1
57	884397	HOUSING	1
83	895567	CHUCK	1
100	884360	SPEED SELECTOR	1
102	884324	CONTACT/LEAD ASSY	1
103	886842	HEATSINK	1
104	884403	FORWARD/REV SELECTOR	1
106	885096	CLUTCH SPRING	10
108	694772	SCREW	10
110	873370	SCREW	10
112	875380	SCREW	10
113	888993	SCREW	10
114	886997	INSULATOR TUBE 120V	1
114	886630	INSULATOR TUBE 120V	1
115	000000-00	No Longer Available	1
120	887791	HOUSING SET CHGR230V	1
120	000000-00	No Longer Available	1
122	893719	CORD	1
122	000000-00	No Longer Available	1
123	887793	TRANSFORMER 230V	1
123	000000-00	No Longer Available	1
124	886340	CIRCUIT BOARD PKG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 9830 Type 1

Item Number	Part Number	Description	Qty Required
125	694015	SCREW	10
126	8300	9.6V BATTERY/9830	1
128	698950	BIT	1
129	884367	CARRYING CASE	1
130	887712	LATCH CARRYING CASE	1
131	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.