




1




866




871



861



2



3

## Parts List for PC180DK-2 Type 1

Item Number	Part Number	Description	Qty Required
1	90542494	DRILL	1
2	90534906	CHUCK	1
3	5103096-01	SCREW	1
861	90532919	KIT BOX	1
866	PC18B	BATTERY PACK	2
866	90543485	18V BATTERY	1
871	90532225	CHARGER	1
871	PCMVC	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.