



Parts List for 2731 Type 1

Item Number	Part Number	Description	Qty Required
1	284111-00	NUT,5/8-11 HEX	1
2	284112-00	WASHER	1
3	429591-00	ON/OFF SWITCH	1
4	791084-00	ADAPTOR	1
6	284108-00	FLANGE	2
7	284106-00	WASHER,GUIDE	2
8	000000-00	No Longer Available	1
9	284107-00	BUTTON,GUIDE	1
10	284105-00	PIN,GUIDE	2
11	284104-00	BOLT,WING	1
12	791131-00	SCREW,SPECIAL	1
12	791131-00	SCREW,SPECIAL	1
13	330016-03	WASHER,PLAIN	1
14	000000-00	No Longer Available	1
15	286444-00	COVER,SIDE	1
16	791123-00	NUT,SPECIAL	2
16	791123-00	NUT,SPECIAL	2
17	286443-00	GUARD	1
18	284117-00	PIN,RUBBER	2
19	284114-00	HOUSING,BEARING	1
20	285964-00	BEARING,BALL	1
21	284113-00	SPINDLE	1
22	284116-00	GEAR	1
23	330003-08	BEARING,BALL	1
24	284121-00	PIN,RUBBER	1
25	284118-00	CASE,GEAR	1
26	284128-00	SPRING,STOP	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 2731 Type 1

Item Number	Part Number	Description	Qty Required
27	284127-00	PIN,STOP	1
28	284132-00	NUT,HEX	3
29	284129-00	HANDLE & COVER	1
30	284190-00	SUPPORT,CORD	1
31	284152-00	BASE	1
32	791072-00	SCREW,M3.5 X 6	4
32	791072-00	SCREW,M3.5 X 6	4
33	284193-00	WASHER,T.L.	4
34	284191-00	SCREW	3
35	284133-00	SCREW	4
36	284130-00	SCREW	2
37	330019-45	SCREW	2
38	284270-00	LABEL,ID	1
39	286441-00	COVER,END	1
40	284136-00	SCREW	2
41	284184-00	SCREW	1
42	000000-00	No Longer Available	1
43	000000-00	No Longer Available	1
44	284265-00	HOUSING,MOTOR	1
45	000000-00	No Longer Available	1
46	791054-00	BRUSH ASSY.	2
47	284267-00	WASHER,WAVY	2
48	284141-00	CAP,BRUSH	2
49	284134-00	FIELD	1
50	20720-00	BEARING,BALL	1
51	284137-00	SCREW	2
52	284123-00	ARMATURE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 2731 Type 1

Item Number	Part Number	Description	Qty Required
53	284139-00	GUIDE,FAN	1
54	284159-00	LEVER,CAM	1
55	284145-00	SHAFT,PIVOT	1
56	284268-00	SCREW,STOP	1
57	000000-00	No Longer Available	1
58	000000-00	No Longer Available	1
59	000000-00	No Longer Available	1
60	284148-00	SCREW	2
61	000000-00	No Longer Available	1
62	284162-00	CLAMP	1
63	98026-25	SCREW	2
64	284156-00	PLATE,INDICATOR	1
65	000000-00	No Longer Available	1
66	284176-00	HANDLE,CRANK	1
67	284180-00	PIN,SPRING	1
68	284271-00	BOLT	2
69	791102-00	FOOT,RUBBER	3
70	429923-00	SCREW & WASHER	3
71	000000-00	No Longer Available	1
72	000000-00	No Longer Available	1
73	284161-00	PLATE,CLICK	1
74	284157-00	PIN,CLICK	1
75	000000-00	No Longer Available	1
76	284147-00	BOLT	2
77	284120-00	RING,O	1
78	000000-00	No Longer Available	1
79	284185-00	CORD & PLUG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 2731 Type 1

Item Number	Part Number	Description	Qty Required
80	330024-41	SCREW,MACHINE	4
81	330003-13	BEARING,BALL	1
82	000000-00	No Longer Available	1
83	284189-00	TUBE,RUBBER	1
84	284181-00	WRENCH	1
85	284131-00	SCREW	1
86	284135-00	HOLDER,BRUSH	2
87	234900-01	PLUG 120V 3WIRE	1
88	53650-00	TERMINAL	4
89	284164-00	BOLT,HINGE	1
90	284174-00	HANDLE,LOCK	1
91	284173-00	SADDLE	1
92	284171-00	MOUNT, VISE	1
93	284777-00	PIN,SPRING	1
94	000000-00	No Longer Available	1
95	284167-00	WASHER,PLAIN	2
96	284523-00	PIN,SPRING	1
97	000000-00	No Longer Available	1
99	284168-00	SCREW,FEED	1
800	790206-00	GREASE, 6 OZ.	1
856	DW8001	14 CH.SW.WHEEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.