



Parts List for 7152 Type 2

Item Number	Part Number	Description	Qty Required
1	148140-01	ARMATURE & FAN	1
2	142959-71	FIELD	1
3	140994-00	BRUSH	2
4	148142-00	RING,BR.& SPRG.	1
6	148147-02	SWITCH	1
7	330073-98	CORD/8 FT/18-2	1
8	158478-00	SINK,HEAT	2
10	157315-00	WASHER,SPRING	1
11	51407-00	WASHER	2
12	283875-00	HOUSING & COVER	1
13	148134-00	GEAR & PINION	1
14	148139-00	BEARING,SPHER.	2
17	148481-00	PROTECTOR,CORD	1
19	148338-00	PLATE,THRUST	1
20	148157-01	SPINDLE,GR&BRG	1
21	903-00	BALL	1
23	330019-04	SCREW,PLASTITE	8
24	679303-00	CHUCK & KEY	1
26	153805-05	NAMEPLATE	1
28	147910-00	ACTUATOR,SWITCH	1
29	157312-00	SCREW,SPEC.,LH	1
30	330001-03	BEARING,SLEEVE	1
31	153834-00	LABEL,IDENT	1
80	147382-00	HOLDER,KEY	1
81	330034-00	KEY,CHUCK	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.