



Parts List for FS100L Type 1

Item Number	Part Number	Description	Qty Required
1	489290-00	UPPER ARM	1
3	90514702	ID LABEL	1
4	489769-00	NUT	1
5	488910-00	CABLE CLAMP	1
6	488829-00	SCREW	2
7	1246079	HHCS METRIC	1
8	1246004	CAP SCREW	2
9	488874-00	LOCK WASHER	2
10	488875-00	BEVEL BRACKET	1
11	488759-00	DUST FINGER	1
12	488766-00	CHEESE HEAD SCREW	1
13	1243456	NUT	3
14	1246175	CAP SCREW	2
15	1349817	SPRING SLEEVE	1
16	1349816	SPRING	1
17	489285-00	WASHER	1
18	488877-00	HANDLE ASSEMBLY	1
19	488793-00	FLAT WASHER	1
20	1243501	SCREW	3
21	1246045	MACH SCREW	1
22	1320101	LOCK WASHER	1
23	1349493	PINCH GUARD	1
24	491549-00	TOOTH WASHER	1
25	488871-00	LOCK NUT	2
26	1349813	PIVOT BOLT	1
27	491647-00	SCREW	1
28	488806-00	GUARD LINK PLATE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for FS100L Type 1

Item Number	Part Number	Description	Qty Required
29	488809-00	SCREW	1
30	488810-00	BUFFER BLOCK	2
31	910816	PIN	1
32	488880-00	O-RING	1
33	1313165	NUT	1
34	492051-00	RING	1
35	488882-00	BEVEL SCALE	1
36	1310016	DR. SCREW	7
37	488812-00	HEX HEAD SCREW	3
38	488813-00	LOCK WASHER	7
39	488846-00	GUARD	1
40	488858-00	SCREW	2
41	488885-00	BRACKET	1
42	1246153	SCREW	1
43	90508227	TRUNNION	1
44	488890-00	STUD	1
47	488815-00	POINTER	1
48	1246117	FL HD SCREW	2
49	488843-00	TABLE INSERT	1
50	488844-00	TABLE	1
51	488808-00	LOCK WASHER	5
53	1342123	LOCK NUT	1
54	577627-00	WASHER	4
55	490117-00	SPRING WASHER	2
56	488819-00	SLIDING FENCE	1
57	90514705	WARNING LABEL	1
61	488816-00	LEVER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for FS100L Type 1

Item Number	Part Number	Description	Qty Required
63	488818-00	FENCE	1
64	488821-00	SCREW	4
66	488822-00	FLAT WASHER	6
67	1330410	ROLL PIN	2
68	488850-00	BRACE	1
69	90508212	BASE	1
72	488854-00	LOCK PLATE	1
73	488855-00	SCREW	1
74	488856-00	POINTER	1
75	488857-00	BRACKET	1
76	489910-00	HANDLE	1
80	1346910	NYLON PAD	8
81	488859-00	LOCK NUT	1
82	488860-00	FLAT WASHER	2
83	488861-00	SPRING WASHER	1
85	488862-00	PIVOT STUD	1
86	488837-00	WARNING LABEL	2
87	90514733	WARNING LABEL	1
91	489339-00	CLAMP ASSEMBLY	1
104	1343019	3/8 GROMMET	1
105	488913-00	SCREW	5
106	1345695	CORD CLAMP	1
108	90512450	BRUSH	2
109	489357-00	BRUSH HOUSING	2
111	489358-00	MOTOR HOUSING	1
115	488808-00	LOCK WASHER	2
116	330019-19	SCREW,PLASTITE	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for FS100L Type 1

Item Number	Part Number	Description	Qty Required
117	90513412	ARMATURE&FIELD	1
118	489159-00	BALL BEARING	1
119	488950-00	BALL BEARING	1
120	489353-00	COVER	1
121	490923-00	PAN HEAD SCREW	1
122	489355-00	PAN HEAD SCREW	1
124	492954-00	HOUSING	1
125	488957-00	BEARING ROLLER	1
126	488958-00	PAN HEAD SCREW	2
127	1243525	LOCKWASHER	5
127	1243525	LOCKWASHER	5
128	490924-00	JACKSHAFT ASSEMBLY	1
130	488968-00	RING	1
131	488969-00	WAVE WASHER	1
133	489376-00	END COVER	1
134	489378-00	LOWER HANDLE	1
135	489160-00	SWITCH	1
136	488974-00	PAN HEAD SCREW	2
137	489379-00	TOP HANDLE	1
138	489919-00	PAN HEAD SCREW	1
139	1246056	CAP SCREW	3
140	903474	JACKSHAFT COVER PLAT	1
141	489377-00	JUMPER	1
142	489383-00	CORDSET	1
143	488979-00	WIRE NUT	1
144	1341235	SCREW	1
144	1341235	SCREW	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for FS100L Type 1

Item Number	Part Number	Description	Qty Required
145	488981-00	TOOTH WASHER	2
150	90514731	DUST BAG	1
151	488823-00	PAN HEAD SCREW	1
153	488820-00	OUTER FLANGE	2
154	488825-00	ARBOR BOLT	1
155	488867-00	CARRIAGE HEAD SCREW	1
156	1342998	SPRING	1
157	489384-00	BLADE GUARD	1
158	489385-00	OUTER PLATE ASSY.	1
159	488826-00	GUARD LINKAGE	1
160	489387-00	SWITCH	1
161	489389-00	LEAD WIRE	1
162	489388-00	BATTERY COVER	1
164	489386-00	BRACKET	1
165	490927-00	WIRE NUT	2
166	A03755	BATTERY SEAT	1
167	489391-00	FLAT HD SCREW	1
168	A03756	SCREW	1
181	90514703	WARNING LABEL	1
182	489381-00	LABEL	1
183	90514692	WARNING LABEL	1
184	90514707	NAMEPLATE	1
185	90514710	ID LABEL	1
186	90514713	WARNING LABEL	1
190	489398-00	INSULATOR SLEEVE	1
203	489294-00	LASER	1
204	489295-00	SCREW	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for FS100L Type 1

Item Number	Part Number	Description	Qty Required
205	489297-00	SET SCREW	1
206	490950-00	CARRIAGE	1
207	A03734	SCREW	1
208	906164	LOCK NUT	1
210	490921-00	PAN HEAD SCREW	2
211	489293-00	NOSE COVER	1
213	1246102	FL.WASHER	1
217	330016-07	WASHER	4
301	1342906	COMBINATION WRENCH	1
302	884299	HEX WRENCH (5MM)	1
303	99056-04	HEX WRENCH	1
304	900225	SCREW	3
846	489925-00	HARDWARE BAG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.