



Parts List for RO100K Type 4

Item Number	Part Number	Description	Qty Required
1	385308-02	ARMATURE & BRG.	1
2	385312-00	FIELD	1
3	89754-01	BRUSH	2
4	85943-02	BRUSH SPRING	2
5	134252-00	HOLDER,BRUSH	2
6	380419-00	BRUSH PLATE ASY	2
7	144960-00	SWITCH (ON-OFF)	1
8	330073-98	CORD/8 FT/18-2	1
9	158498-00	BEARING,SPHER.	1
10	330003-03	BEARING,BALL	1
11	385341-06	CLAMSHELL (SET)	1
12	380402-00	FAN	1
13	144983-07	COVER,SWITCH	1
15	158477-00	TERMINAL	2
16	448387-00	TERMINAL	4
17	148481-00	PROTECTOR,CORD	1
18	133669-00	CLAMP,CORD	1
19	380405-00	RETAINER,BRG.	1
20	330003-12	BEARING,BALL	1
21	151652-00	WASHER,CONE	1
22	380413-00	SPACER	1
23	380278-00	PAD,H & L	1
24	380410-00	SEAL	1
27	145312-00	PLUG,RUBBER	2
28	330019-02	SCREW,PLASTITE	6
29	330019-13	SCREW,M4X19	4
30	98012-11	SCREW,MACHINE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for RO100K Type 4

Item Number	Part Number	Description	Qty Required
31	604163-00	NAME PLATE	1
32	604166-00	ID LABEL	1
33	381474-00	BAFFLE	2
34	37653-00	RING,RETAINING	1
35	147443-00	PLATE,SWITCH	1
40	387111-00	DUST BAG ASM	1
45	607690-00	WARNING LABEL	1
861	617799-00	KIT BOX	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.