

# Breville

## AVANCE RICE DUO 10 CUP RICE COOKER




<b>Description:</b>	Large 10 cup rice cooker with stainless steel body, non stick removable cooking bowl, toughened cook n' look glass lid, selector lever control, ready bell, removable cord, cooking and warming lights, stainless steel steaming trays plus a measuring cup and serving spoon		
<b>Colour:</b>	Brushed Stainless Steel with black		
<b>Voltage:</b>	<b>AU/NZ</b>	<b>RC19 - 230-240V 50Hz 700W</b>	<b>First Sale Date: 12/02/2003</b>
	<b>CANADA</b>	<b>BRERC19XL- 120V 60Hz</b>	<b>First Sale Date:</b>
	<b>US</b>	<b>RC19XL - 120V 60Hz</b>	<b>First Sale Date:</b>
<b>Services:</b>	<p><b>English:</b> Parts are available as per Spare Parts listing. Availability of parts may vary depending on the country where the product is sold. Whilst the diagrams shows all parts available, but parts available for a particular country may differ.</p> <p><b>French:</b> Les pièces sont disponibles selon la liste des pièces de rechange. La disponibilité des pièces peuvent changer selon le pays où le produit est vendu. Tandis que les diagrammes montre toutes les pièces disponibles, mais celles-ci peut différer pour un pays particulier.</p> <p><b>Spanish:</b> Las partes de repuesto son disponibles al correspondido de la lista de partes de repuesto. Las partes disponible pueden diferenciar con acuerdo del país donde el producto sea vendido. Durante el diagrama demuestre que las partes de repuesto son disponibles, pero partes disponibles parra un país en particular pueden ser diferentes.</p>		

Spare Parts Listing

Note: Substitute Items only apply to AU/NZ

NO	CANADA	US	AU/NZ	DESCRIPTION	SUBS. ITEM
01	BPRC1901	RC19XL/01	RC19/01	GLASS LID WITH KNOB COMPLETE	
07	BPRC1907	RC19XL/07	RC19/07	STEAMER BOWL-SMALL	
08	BPRC1908	RC19XL/08	RC19/08	STEAMER BOWL-LARGE	
09	BPRC1909	RC19XL/09	RC19/09	ALUMINIUM INNER POT	
10	BPRC1910	RC19XL/10	RC19/10	THERMOSTAT ASSEMBLY	
11	BPRC1911	RC19XL/11	RC19/11	ELEMENT-HEAT PLATE	
17	BPRC1917	RC19XL/17	RC19/17	MICRO SWITCH	
20	BPRC1920	RC19XL/20	RC19/20	LEVER CONTROL ASSY COMPLETE	
27	BPRC1927	RC19XL/27	RC19/27	KEEP WARM HEATER-ELEMENT ASSY	
33	BPRC1933	RC19XL/33	RC19/33	SIDE HANDLE	
38	BPRC1938	RC19XL/38	RC19/38	SWITCH ACTUATOR	
45	BPRC1945	RC19XL/45	RC19/45	FIBREGLASS SLEEVING	
46	BPRC1946	RC19XL/46	RC19/46	MICROTEMP 157C	
48	BPRC1948	RC19XL/48	RC19/48	RUBBER FEET	
50	BPRC1950	RC19XL/50	RC19/50	REMOVABLE POWER CORD	
71	BPRC1971	RC19XL/71	RC19/71	MICROTEMP 172c - TC01	
72	BPRC1972	RC19XL/72	RC19/72	MEASURING CUP	
73	BPRC1973	RC19XL/73	RC19/73	SPATULA	
75	BPRC1975	RC19XL/75	RC19/75	INSTRUCTIONS	

Circuit Diagram



Exploded View

