

# The Ultimate Portable Garage Air Compressor

Operating Instructions and Parts Manual

#### WL6701 and WL6703

FRANÇAISE: Page FR-1 ESPAÑOL: Página SP-1



MAKES IT **EASY** TO DO IT *LIKE A PRO* 

Visit us at chpower.com

# The Ultimate Portable Garage Air Compressor



#### **Description**

Oilless compressors are designed for do-it-yourselfers with a variety of home and automotive jobs. These compressors power spray guns, impact wrenches and other tools. These units operate without oil.



Figure 1 - WL6701 and WL6703

#### **Specifications**

WL6701 and WL6703

**Running HP: 1.7 (ISO 1217)** 

Free Air CFM: 3.8 @ 90 psi (ISO 1217)

Free Air CFM: 5.6 @ 40 psi (ISO 1217)

Tank Capacity (gallons):

18, 22, 26, or 30

Volts, Phase: 120 V, single

Amp Draw: 15

Max. Duty Cycle: 50%

Record the model number and serial number, located on the back of the tank, and date of purchase in the space below.

Model #: \_\_\_\_\_

Serial #: \_\_\_\_\_

Date of Purchase: \_


Retain these numbers for future reference.

## For Replacement Parts or Technical Assistance, Call 1-800-543-6400

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address any correspondence to:
Campbell Hausfeld
Attn: Customer Service
100 Production Drive
Harrison, OH 45030 U.S.A.



Ref. No.	Description	Part No.	Qty.		
1	Motor assembly kit				
	(Includes #2, 3, 6, 7, 10, 12, & 14)	WL019100SJ	1		
2	Cylinder gasket	<b>A</b>	1		
3	Intake valve	<b>A</b>	1		
4	Valve plate	<b>A</b>	1		
5	Exhaust valve	<b>A</b>	1		
6	Head gasket	<b>A</b>	1		
7	Exhaust valve gasket	<b>A</b>	1		
8	Head	WL010500AV	1		
9	Piston assembly (Includes #10)	WL211000SJ	1		
10	Piston bolt	ST071804AV	1		
11	Head bolt	•	4		
12	Fan	WL008400AV	1		
13	Compression connector	ST159001AV	1		
14	Belt kit (Includes #10, 12,				
	RIT valve, & ferrules)	WL047300SJ	1		
REPLACEMENT PARTS KITS					
•	Head bolt kit				
	(Set of 4 ea., part #11)	WL211100AJ	1		
	Valve plate kit (Includes #2-7)	WL211201SJ	1		

Replacement Parts List for Pump, Model WL390100

### TORQUE REQUIREMENTS

Piston Bolt	350 - 450 in. Ibs.
Head Rolts	90 - 120 in The

Figure 20 – Repair Parts Illustration for pump, model WL390100

## For Replacement Parts or Technical Assistance, Call 1-800-543-6400

Please provide following information:

- Model number
- Serial number (if any)
- Part description and number as shown in parts list

Address any correspondence to:

Campbell Hausfeld Attn: Customer Service 100 Production Drive

Harrison, OH 45030 U.S.A.




Figure 21 - Repair Parts Illustration for The Ultimate Portable Garage Air Compressor, model WL6701 and WL6703

# **Replacement Parts List for The Ultimate Portable Garage Air Compressor**

Ref. No.	Description	Part No.	Qty.
1	18 Gallon Tank	AR063600CG	1
	26 Gallon Tank	AR062700CG	1
2	Rubber Grommet	WL008000AV	1
3	Bottom Front Shroud	WL045000AV	1
4	Lower Caster Side Shroud	WL044900AV	1
5	Millenium Pump/Motor Assembly	WL212000SJ	1
6	Caster Swivel Wheel - 2 in. Diameter	<b>A</b>	2
7	Check Valve	CV309100AV	1
8	Pressure Switch	CW218300AV	1
9	Pump/Motor Shroud		1
10	#8 X .375 Self-Tapping Screw	•	4
11	Push Type - Straight Tube Fitting	ST119305AV	1
12	Exhaust Tube	•	1
13	Instant Air Tube	•	1
14	Filter	WL026100AV	1
15	Strain Relief	WL012700AV	1
16	Power Cord	EC012601AV	1
17	Top Skirt	WL044700AV	1
18	Top Shroud	WL044600AV	1
19	1/4 in. X 1.50 in. Plastic Screw	▼	2
20	1/4-20 X .75 Self-Tapping Screw	▼	12
21	Regulator Assembly	RE300200AV	1
22	Regulator Knob	•	1
23	#10 X .75 Self-Tapping Screw	•	1
24	Regulator Knob Cover	•	1
25	3 in. Outlet Gauge	GA032700AV	1
26	1/4" NPT Male Universal Coupler	HF203300AV	1
27	Washer - Plain Type "A"	▼ ★	6
28	Torx Button Head Screw	▼ ○ ★	10
29	Control Panel without Switch	WL042200AV	1
30	Handle		1
31	1/4-20 X 1.25 Self-Tapping Screw		4
32	On/Off Switch	ST196400AV	1
33	On/Off Pedal	WL044500AV	1
34	Eccentric Cover	WL044400AV	1
35	Motor Bracket	BA018300AV	1

All UUIII	ipi coooi				
Ref. No.	Description	Part No.	Qty.		
36	Wheel - 10" OD Black Hub	WA004000AV	2		
37	Axle Bolt	ST033400AV	2		
38	Wheel Cog Gear	*	1		
39	Brake Bracket Mount	*	1		
40	Brake Locking Arm	*	1		
41	#8 X 1.50 in. Plastic Screw	0	4		
42	#12 X 1.75 in. Plastic Screw	O	4		
43	Hex Keps Nut	<b>A</b>	2		
44	Drain Valve	D-140700AV	1		
45	Jam Nut and Washer Set	×	1		
46	Drain Knob and Screw	WL046100AV	1		
47	Pressure Gauge, 1.5 in. Diameter	GA032900AV	1		
48	1/4 - 18 Pipe Plug	†	1		
49	Drain Shroud and Cup	×	1		
50	Drain Tube with Weight	WL046300AV	1		
51	Safety Valve	V-215106AV	1		
52	Tube to Hose Fitting	ST196000AV	1		
53	50 ft. Recoil Hose	MP287400AV	1		
54	Screw - Hex Head Machine	*	1		
55	Lever Safety Blow Gun	MP216700AV	1		
56	Tire Inflation Valve with Whip Hose	HF229900AV	1		
57	Blowgun Inflator Kit	MP211600AV	1		
REPLACEMENT PARTS KITS					
<b>A</b>	Caster Wheel Kit	WA005900SJ			
	Shroud kit	WL042900SJ			
•	Exhaust Tube Kit (includes nuts and ferrules)	WL046600SJ			
•	Instant Air Tube Kit	000000			
•	(includes nuts and ferrules)	WL046900SJ			
$\blacksquare$	Upper Shroud Hardware Kit	ST172200SJ			
•	Regulator Knob Kit	RE300300SJ			
	Handle Kit (18 Gallon Tank) Handle Kit (26 Gallon Tank)	HL039200SJ HL037700SJ			
О	Lower Shroud Hardware Kit	ST172300SJ			
*	Brake Assembly	WL047000SJ			
×	Shroud And Drain Cup Assembly	WL046200SJ			

Standard Hardware Item