



Parts List for DC528 Type 1

Item Number	Part Number	Description	Qty Required
1	5140027-34	HANDLE HOUSING	1
3	5140027-35	TOP HOUSING ASSY	1
867	608522-00	BATTERY CAP	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.