



Parts List for DC720KA Type 1

Item Number	Part Number	Description	Qty Required
1	640567-00	CLAMSHELL SET	1
2	648984-00SV	TRANSMISSION ASSY.	1
3	640548-00SV	ARMATURE&PINION	1
4	648115-00	MAGNET RING	1
5	640550-00	BRUSH HLDR/BRUSH ASY	1
6	640555-00	BRUSH HLDR/BRUSH ASY	1
7	645373-00	CLAMP,BEARING	1
8	645393-00	SHIFTER ASSEMBLY	1
9	642891-00	REVERSE LEVER	1
10	152274-29	VSR SWITCH	1
11	682211-00	SCREW,TORX	12
12	148354-03	BIT CLIP	1
13	607918-41	SCREWDRIVER BIT	1
14	330075-74	KEYLESS CHUCK	1
15	605256-01	SCREW	1
16	650190-00	IDENT. LABEL	1
17	655954-00	NAMEPLATE	1
18	632733-00	ADAPTER	1
19	391896-00	SHIFTER WIRE	1
861	637475-00	LATCH ASSEMBLY	2
861	380865-02	KIT,HANDLE	1
861	652211-00	KITBOX	1
866	651034-01	BATTERY PACK	1
867	645221-00	BATTERY CAP	1
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.