



Parts List for DC750KA Type 1

Item Number	Part Number	Description	Qty Required
1	631616-01	HOUSING & COVER	1
2	389080-00	BUTTON(FWD/REV)	1
3	389081-01	TERMINAL BOARD	1
4	391092-00	LEAD,RED	1
5	391091-00	LEAD,BLACK	1
6	682211-00	SCREW,TORX	1
7	391996-00	SHIFTER ASSY.	1
8	631445-01	MOTOR & PINION	1
11	330075-87	CHUCK	1
12	638563-01	TRANSMISSION ASSY.	1
13	149518-01	SCREW	1
14	152274-18	SWITCH	1
15	395657-00	ID LABEL	1
16	148354-03	BIT CLIP	1
17	607918-41	SCREWDRIVER BIT	1
18	642114-00	LABEL	1
20	562160-01	SCREW	2
21	640358-00	NAMEPLATE	1
22	389083-00	PLATE	1
861	389108-00	KIT BOX	1
866	398908-00	BATTERY PACK	2
871	391675-00	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.