



⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530057566	Assy - Throttle Cable	18.	530015224	Screw
2.	530058000	Trigger	19.	530016014	Screw
3.	530058751	Throttle Hsg. (Right)	20.	530096099	Assy - Gearbox
4.	530016406	Screw	21.	530016152	Wingnut
5.	530015814	Screw	22.	530095772	Assy - Hub.
6.	530015786	Bolt - Handle	23.	530053241	Spring
7.	530058750	Throttle Hsg. (Left)	24.	530401957	'Retainer
8.	530058754	Handle - Assist	25.	952711551	Accy - Spool w/Line
9.	530016152	Wingnut - Handle	26.	952711550	Accy - Head TNG VI Assy.
10.	530071780	Assy - Drive Shaft Hsg.	Not Shown		
11.	530015805	Screw	↗	545186739	Operator Manual
12.	530096169	Shaft - Flex		530058594	Decal - Start Inst.
13.	530052285	Line Limiter		530058597	Decal - Choke
14.	530015814	Screw		530055350	Decal - Shaft Warning
15.	530015820	Bolt - Shield			
16.	530071823	Kit - Shield Assy (Incl.13,14)			
17.	545150701	Bracket - Shield			

