



Parts List for DCD780C2 Type 1

Item Number	Part Number	Description	Qty Required
1	N031365	TRANSMISSION ASSY.	1
2	N061233	CLAMSHELL SET	1
3	N089939	SWITCH VSR	1
4	682211-00	SCREW,TORX	12
5	654258-00	BRUSH RING ASM	1
6	N039788	FORWARD/REV SELECTOR	1
7	N092054	CHUCK,KEYLESS	1
8	N035580	MAGNET RING	1
9	N042178	ARMATURE ASSEMBLY	1
10	N092854	CHUCK SCREW	1
11	N078822	IDENT. LABEL	1
13	N071836	ROLL PIN	1
14	N042665	MACHINE SCREW	2
15	N086039	BELT HOOK	1
16	N098881	BIT HOLDER ASSY	1
24	N078823	WARNING LABEL (SPA)	1
25	N078824	NAMEPLATE	1
800	N017298	GREASE	1
861	N068611	KITBOX	1
866	DCB201	BATTERY PACK	2
871	DCB101	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.