

Parts List for DWD112 Type 1

Item Number	Part Number	Description	Qty Required
1	647146-00	HOUSING SET	1
4	643441-00	FIELD	1
5	653476-00	ARMATURE	1
6	649381-00	VSR SWITCH	1
7	330005-01	PROTECTOR,CORD	1
8	330072-98	CORD/8FT/18-2SJ	1
9	647142-02	BRUSH BOX ASSY	1
10	647142-03	BRUSH BOX ASSY	1
11	649380-00	BRUSH	2
12	330019-13	SCREW,M4X19	7
13	143845-00	LEVEL	1
15	655011-00	ID LABEL	1
16	464292-00	DEFLECTOR	1
21	330003-04	BEARING,BALL	3
22	389216-00	GEAR	1
23	605040-23	BALL BEARING	1
24	605505-00	SPINDLE	1
25	330075-47	KEYLESS CHUCK	1
25	330075-47	KEYLESS CHUCK	1
25	330075-47	KEYLESS CHUCK	1
25	330075-47	KEYLESS CHUCK	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
861	653885-00	KIT BOX	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.